



ITEM	PARTS NAME	ITEM	PARTS NAME	ITEM	PARTS NAME	ITEM	PARTS NAME
101	DEFLECTOR	204	VALVE PLUNGER	407	SPRING A COMPERSSION	429	MAGAZINE SHAFT PIN
102	BOLT ASSY	205	O - RING	408	FEED BUMPER	430	LOCK NUT
103	HEX.SOC.HD.SCREW	206	O - RING	409	FEED PISTON CAP	431	FLAT WASHER
104	CAP	207	SPRING	410	FEED FINGER	432	BOLT CAP
105	SEAL	208	PLUNGER	411	FEED FINGER SPRING	433	PROTECTIVE CASING
106	COMPRESSION SPRING	209	O - RING	412	PIN FEED PISTON	434	SAFETY A
107	OIL SEAL	210	TRIGGER VALVE HEAD	413	PU RETAINER	435	RING
108	O - RING	211	SPRING PIN	414	DOOR SHAFT PIN	436	ADJUST AXIE
109	HD.VALVE PISTON	212	SPRING PIN	415	DOOR	437	SAFETY B
110	O - RING	214	TRIGGER UNIT	416	STOPPER FINGER SPRING	438	SAFETY SPRING
111	PACKING	222	SPRING	417	FIRST STOPPER FINGER	439	SAFETY COVER
112	PISTON RING	301	GUN BODY UNIT	418	SECOND STOPPER FINGE	440	HEX.SOC.HD.BOLT
113	O - RING	302	END CAP	419	PIN-NAIL STOP	441	STOPPER
114	DRIVER UNIT	303	O - RING	420	PIN	442	E - RING
115	CYLINDER	304	AIR PLUG	421	LATCH SPRING	443	O - RING
116	O - RING	305	DUSTY COVER	422	DOOR LATCH	444	C - RING
117	CYLINDER RING	401	O - RING	423	MAGAZINE CASE	445	FIXED RING
118	BUMPER	402	NOSE PIECE	424	SPRING BASE	446	FIXED PIN
119	CYLINDER PRESS RING	403	SAFETY GUIDE	425	SPACER	447	MUZZLE PROTECTOR
201	O - RING	404	O - RING	426	PULL SPRING	448	BOLT ASSY
202	O - RING	405	FEED PISTON	427	SPRING BASE A		
203	PLUNGER CAP	406	O - RING	428	MAGAZINE COVER		