



ITEM	PARTS NAME	ITEM	PARTS NAME	ITEM	PARTS NAME	ITEM	PARTS NAME
101	COUNTER SUNK SCREW	126	O - RING	304	DUSTY COVER	424	SAFETY
102	WASHER	127	BUMPER	305	AIR PLUG	425	SAFETY SPRING
103	RUBBER PAD	201	O - RING	401	O - RING	426	DOOR SHAFT PIN
104	DEFLECTOR	202	PLUNGER CAP	402	O - RING	427	MAGAZINE CASE
105	MUFFLER	203	O - RING	403	NOSE PIECE	428	MAGAZINE POST
106	O - RING	204	O - RING	404	HEX.SOC.HD.BOLT	429	RUBBER RING
107	HEX.SOC.HD.SCREW	205	VALVE PLUNGER	405	O - RING	430	SPRING BASE
108	HEX.SOC.HD.BOLT	206	O - RING	406	FEED PISTON	431	SPACER
109	GUIDE COVER	207	SPRING	407	O - RING	431	SPACER
110	CAP	208	O - RING	408	PUSHER SPRING B	432	SPACER
111	WASHER SEAL	209	PLUNGER	409	FEED BUMPER	433	PULL SPRING
112	SEAL	210	TRIGGER VALVE HEAD	410	PUSHER SPRING A	434	MAGAZINE COVER
113	COMPRESSION SPRING	211	PIN	411	ROD	435	PIN FEED PISTON
114	O - RING	212	COVER-PLUNGER	412	FEED PISTON CAP	436	FEED FINGER
115	O - RING	213	O - RING	413	C - RING	437	FEED FINGER SPRING
116	WASHER	214	O - RING	414	DOOR LATCH	438	HEX.SOC.HD.BOLT
117	HD.VALVE PISTON	215	SPRING PIN	415	LATCH SPRING	439	PROTECTOR WASHER
118	CYLINDER CAP SEAL	216	SECONDARY TRIGGER	416	DOOR	440	FLAT WASHER
119	O - RING	217	TRIGGER	417	PU RETAINER	441	SPRING COVER
120	DRIVER UNIT	218	SPRING PIN	418	SPRING PIN	442	MAGAZINE SHAFT PIN
121	COLLAR	219	SPRING PIN	419	STOPPER FINGER SPRING	443	BOLT CAP
122	CYLINDER	220	SPRING PIN	420	NAIL STOP	444	SAFETY GUIDE
123	O - RING	301	GUN BODY UNIT	421	PIN-NAIL STOP	445	SPRING BASE A
124	CYLINDER RING	302	O - RING	422	MUZZLE PROTECTOR		
125	CYLINDER SPACER	303	END CAP	423	DUST SHIELD PLUG		